

INSTALLATION INSTRUCTIONS

PART NO. 52-942WI

ACCESSORY SUB-HARNESS

FITMENT: HONDA GOLDWING/TOUR 2018-NEWER

11/13/2018

TOOLS NEEDED: 6MM ALLEN WRENCH

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. USE REMOVABLE THREAD LOCK ON ALL SCREWS.**ESTIMATED INSTALLATION TIME: 30 TO 45 MIN.****INSTALLATION:**

1. OPEN BOTH SADDLEBAGS AND REMOVE THE SIDE COVER FROM EACH SIDE OF THE BIKE (**FIG. 1**).
2. USE A 6MM ALLEN WRENCH TO REMOVE THE TWO SEAT BOLTS (**FIG. 2 SHOWS LEFT SIDE**). UNPLUG THE SEAT HARNESS CONNECTOR ON THE RIGHT SIDE OF THE BIKE (**FIG. 3**) AND REMOVE THE SEAT BY LIFTING THE FRONT OF THE SEAT AND PULLING FORWARD TOWARDS THE FRONT OF THE BIKE.
3. LOCATE THE LEFT AND RIGHT SADDLEBAG CONNECTORS (**FIG. 4**) AND DISCONNECT BOTH LEFT AND RIGHT SADDLEBAG CONNECTORS.
4. USE **FIG. 5** TO DETERMINE LEFT AND RIGHT ACCESSORY SUB-HARNESS PLUGS. **FIG. 5** ALSO SHOWS WIRE FUNCTIONS FOR CONNECTING ACCESSORIES TO THE ACCESSORY SUB-HARNESS.
5. INSERT THE LEFT CONNECTOR FROM THE ACCESSORY SUB-HARNESS TO THE LEFT SADDLEBAG CONNECTORS AS SHOWN IN **FIG. 6**.
6. INSERT THE RIGHT CONNECTOR FROM THE ACCESSORY SUB-HARNESS TO THE RIGHT SADDLEBAG CONNECTORS AS SHOWN IN **FIG. 6**.
7. TUCK THE CONNECTORS AND WIRES DOWN AND OUT OF THE WAY SO THEY DO NOT GET PINCHED OR PULLED WHEN SEAT IS INSTALLED.
8. REASSEMBLE THE GOLDWING IN REVERSE ORDER.



