



GOLDSTRIKE™ LEFT SIDE PERCH MOUNT

Parts Included:

- 1 Left Side Accessory Perch Mount

Installation Instructions:

1. Remove the Phillips head screw located on the front side of your left hand control clamp. (Fig. 1)
2. Remove the clamp half.



3. Hook the lower edge of the GoldStrike™ perch mount to the detent in the controls. Be sure the wire runs above the perch mount and is not crushed. (Fig. 2)
4. Use the screw you removed in step one to bolt the perch mount to your controls. (Fig. 3)



5. Adjust the angle of the ball mount using the allen head screw indicated in figure 3. Once you are satisfied with the angle, tightened it down and attach your desired accessory.

DO
NOT
OVERTIGHTEN

WARNING:
This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:
This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:
This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:
Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit our website Ciro3d.com for our complete warranty policy.

CIR03D.COM

G0058111, REV. -



GOLDSTRIKE™ SMARTPHONE HOLDER

Parts Included:

- 1 Smartphone Holder Assembly

Installation Instructions:

1. Remove the large plastic nut from your smartphone holder and slide it over the ball mount with the threads facing outward.



2. Snap your smartphone holder onto the ball and thread the large plastic nut onto the smartphone holder. Adjust the angle and tighten it down.
3. Flip up the side lever on the smartphone holder and adjust it to the size of your phone. Your device should have just enough space to slide in and out. When adjusted correctly, flip the lever down to secure your device.

*Note: The lever can be put on either side if unscrewed all the way.

WARNING:
This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:
This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:
This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:
Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit our website Ciro3d.com for our complete warranty policy.

CIR03D.COM

G0058001, REV. -