

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.



Installation Instructions:

1. Park on level surface and shut off motorcycle. Ensure engine has time to cool before installation.

- 2. Pull out mirror at bottom edge until it stops. Fig. 1a
- 3. Pull mirror firmly at bottom. It will snap loose. Fig. 1b
- 4 Pull the top of mirror out until it stops. Lift disconnected bottom of mirror and pull down to release mirror. Fig. 2
- 5. Note the tabs on the mirror in Fig. 3. The tabs are the same on the new mirror and go on in the reverse order. At an angle shown in Fig. 2 slide the tabs in and up till engaged and push bottom of mirror in until clips snap onto bars and you hear a click.
- 6. Repeat steps 2-5 on other side of motorcycle.

ATTENTION When adjusting mirror always push mirror instead of pulling to avoid accidentally pulling mirror loose at the bottom.







