

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright © 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-929

BRAKE PEDAL COVER

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

11/14/2018

TOOLS NEEDED: 3MM ALLEN WRENCH

REMOVABLE THREAD LOCK

CLEAN RAG

CLEANER

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**ESTIMATED INSTALLATION TIME: 10 TO 15 MIN.****INSTALLATION:**

1. CLEAN BRAKE PEDAL THOROUGHLY.
2. LET DRY COMPLETELY.
3. APPLY REMOVABLE THREAD LOCK TO EACH SUPPLIED SET SCREW AND PARTIALLY THREAD INTO THE BOTTOM OF THE BRAKE PEDAL COVER.
4. SLIDE BRAKE PEDAL COVER ALL THE WAY OVER THE BRAKE PEDAL WITH THE RUBBER INSERT FACING UP UNTIL IN STOPS.
5. TIGHTEN THE TWO SET SCREWS: **ALTERNATE BETWEEN THE TWO SET SCREWS TIGHTENING A LITTLE BIT EACH TIME UNTIL THEY ARE BOTH TIGHT AND THE BRAKE PEDAL COVER DOES NOT MOVE.**

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Copyright © 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 52-929

BRAKE PEDAL COVER

FITMENT: HONDA GOLDWING/GOLDWING TOUR 2018-NEWER

11/14/2018

TOOLS NEEDED: 3MM ALLEN WRENCH

REMOVABLE THREAD LOCK

CLEAN RAG

CLEANER

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.**ESTIMATED INSTALLATION TIME: 10 TO 15 MIN.****INSTALLATION:**

1. CLEAN BRAKE PEDAL THOROUGHLY.
2. LET DRY COMPLETELY.
3. APPLY REMOVABLE THREAD LOCK TO EACH SUPPLIED SET SCREW AND PARTIALLY THREAD INTO THE BOTTOM OF THE BRAKE PEDAL COVER.
4. SLIDE BRAKE PEDAL COVER ALL THE WAY OVER THE BRAKE PEDAL WITH THE RUBBER INSERT FACING UP UNTIL IN STOPS.
5. TIGHTEN THE TWO SET SCREWS: **ALTERNATE BETWEEN THE TWO SET SCREWS TIGHTENING A LITTLE BIT EACH TIME UNTIL THEY ARE BOTH TIGHT AND THE BRAKE PEDAL COVER DOES NOT MOVE.**