

Copyright© 2018 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. HG18MB

TANK MINI BRA

FITMENT: HONDA GOLDWING/ GOLDWING TOUR 2018-NEWER

3/29/2018

TOOLS NEEDED: 6MM ALLEN WRENCH

LINT FREE TOWEL

RUBBING ALCOHOL

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

ESTIMATED INSTALLATION TIME: 30 TO 40 MIN.

INSTALLATION:

1. OPEN BOTH SADDLEBAG LIDS AND REMOVE BOTH SIDE PANELS.
2. USING A 6MM ALLEN WRENCH REMOVE THE TWO SCREWS NEAR THE FRONT OF THE SEAT. SEE FIG. 1.
3. ON THE RIGHT SIDE UNPLUG THE CONNECTOR FOR THE SEAT. SEE FIG. 2.
4. LIFT THE FRONT OF THE SEAT AND PULL IT FORWARD TO REMOVE IT.
5. USING RUBBING ALCOHOL AND A LINT FREE TOWEL CLEAN THE AREA SHOWN IN FIG. 3 ON BOTH SIDES. LET DRY.
6. REMOVE THE 7" LONG PIECES OF HOOK FROM BOTH TANK MINI BRAS AND ATTACH IT TO THE BIKE AS SHOWN IN FIG. 4.
7. REMOVE THE 13" LONG PIECE OF HOOK WITH A MITER ON ONE END FROM THE LEFT MINI BRA AND ATTACH IT TO THE BIKE AS SHOWN IN FIG. 5.
8. REPEAT STEP 7 ON THE RIGHT SIDE.
9. INSTALL THE LEFT BRA FIRST BY ATTACHING THE LOOP ON THE LONG BOTTOM EDGE TO THE 13" PIECE OF HOOK. PULL TIGHT AND ATTACH THE TOP TO THE 7" PIECE OF HOOK. SEE FIG. 6.
10. REPEAT STEP 9 FOR THE RIGHT SIDE.
11. REINSTALL THE SEAT AND SIDE PANELS. REMEMBER TO RECONNECT THE SEATS CONNECTOR.

